



La-z-boy Remote (LR) Code List

TV		01
ABEX	0401	CONCIERGE 1781
ADMIRAL	0681 1441 1661	CONTEC 0011 1911 1941
ADVENT	0631 2131	2191
ADVENTURA	0151	CORNEA 1471
AIKO	1011	CRAIG 1941 2191
AIWA	0411 0651 0931	CROSLEY 1961
	1411	CROWN 1941 2191
AKAI	0351 0781 1901	CTX 1441
ALLERON	1711	CURTIS MATHES 0001 0261 0351
AMARK	1441	1191 1221 1261
AMTRON	2191	1311 1421 1551
ANAM NATIONAL	0271 1941 2151	1661 1691
	2191 2331	CXC 1941 2191
AOC	0001 0011 0251	DAEWOO 0001 0221 0251
	0391 0611 0891	0591 0721 0831
	1221	0971 1011 1081
APEX	0191 0431 0671	1221 1231 1251
	1891	1431 1501 1521
ARCHER	1441	1551 1561 1941
ASPECT	1271	2181
AUDIOVOX	2191	DAYTRON 0001 1221
AXION	0881	DELL 1401 2041
BELCOR	0001	DIAMOND VISION 1211 1611 2001
BELL & HOWELL	1261 1421 1661	DIGISTAR 0381 0581 0871
	1691	1061 2451
BENQ	1741 1761 2221	DIMENSIA 1421 1691
BRADFORD	2191	DISNEY 1101
BROKSONIC	0211 0371 0851	DUKANE 1271 1981
	1631	DUMONT 0001 1781
BROKWOOD	0001	DURABRAND 0371 0861 0921
CANDLE	0001 0151 0961	1381 2291
	1221	DYNASTY 1941
CAPEHART	0391	ELECTROBAND 0011 1901
CELEBRITY	1901	ELECTROHOME 0001 1221 1921
CELERA	0191	2151
CENTRIOS	1361	ELEKTRA 1661
CENTURION	1221	ELITE VIDEO 0901
CETRONIC	1941	EMERSON 0001 0021 0031
CHANGHONG	0191 1891	0041 0271 0281
CITIZEN	0001 0351 0371	0291 0371 0441
	0961 1011 1221	0451 0691 0701
	1311 1381 1661	0731 0741 0851
	1941 2191	0931 1221 1251
CLAIRTONE	0011	1261 1371 1381
CLASSIC	0191 1891 1941	1451 1461 1551
CLP	0061	1631 1681 1701
CLP CLASSIC	0001 0041 0161	1711 1931 1941
COBY	2511 2521 2531	2171 2191 2361
	2541 2551	ENVISION 0001 0071 1221
COLOR VOICE	1431	FISHER 1161 1261 1531
COLORTYME	0001 1221 1431	1581 1911
CONCERTO	0001 1221	FUJITSU 0901 1711

TV 02

FUNAI	0701 0931 1381	KEC	1941
	1711 1941 2191	KENWOOD	0001 1221
FUTURETEC	1941 2191	KLH	0191
GATEWAY	0501	KLOSS NOVABEAM	0151 1021
GE	0001 0041 0051	KONKA	0471 0521 0751
	0141 0261 0361		1241 1671 2121
	0791 0811 1221		2191 2241 2371
	1421 1691 1921	KTV	0011 1491 1681
	1951 2111 2151		1941 2191
GIBRALTER	0001 1781	KURAZAI	1661
GOLDSTAR	0001 0251 0611	LASONIC	1211 1611
	0761 0931 1181	LG	0001 0251 0611
	1221 1501 1911		0761 0931 1181
	1711 2191		1221 1471 1501
GRUNDY			1911
GUESTVISION	1861	LIQUIDVIDEO	0881 1111
HAIER	0671 0861 0921	LODGENET	1421 1661 1691
	1741		2091
HALLMARK	0001 1221	LOEWE	1871 1961
HARVARD	2191	LOGIK	1421 1661 1691
HISENSE	0671 2081 2211	LUCE	0301
HITACHI	0001 0841 0931	LUXMAN	0001 1221
	1041 1221 1271	LXI	0001 0261 0811
	1341 1371 1481		0931 1221 1261
	1661 1721 1751		1311 1421 1691
	1801 1911 1981		1961
	2051	MAGNASONIC	1711
ILO	1141 1971 2391	MAGNAVOX	0001 0321 0681
	2481		0701 0961 1021
IMA	2191		1171 1221 1801
INFINITY	1171 1961		1961 2321
INITIAL	2481	MAJESTIC	1421 1661 1691
INSIGNIA	0371 0581 0701	MARANTZ	0001 1221 1841
	0871 0921 1241		1961
	1381 2241 2271	MEDION	1101 1141 2351
INTEGRA	1841	MEGATRON	0001 1221 1271
INTEQ	1781	MEI	0011
JANEIL	0151	MEMOREX	0001 0371 1161
JBL	1961		1221 1261 1421
JC PENNEY	0001 0051 0251		1631 1661 1691
	0261 0351 0791		1711
	0811 0961 1221	MGA	0001 0251 1221
	1311 1421 1451		1581 1711 1801
	1691 1911 1921		1911 1921
	1951	MIDLAND	0051 0261 0811
JCB	1901		1691 1781
JENSEN	0001 1221 2271	MINUTZ	1951
JVC	0311 0481 0771	MITSUBISHI	0001 0251 1221
	0901 0941 1281		1581 1711 1801
	1481 1801 1911		1811 1921
	2381	MONIVISION	0491
KAWASHO	0001 1221 1901	MONTGOMERY WARD	1421 1661 1691
KAYPANI	0391		

TV 03

MOTEVA	1261	PRECISION	0621
MOTOROLA	1441 2151	PRICE CLUB	0351
MTC	0001 0011 0251	PRIMA	0381 0581 0871
	0351 1221 1311		2451
MULTITECH	2191	PRINCETON GRAPHICS	1301 1441
MULTIVISION	0081	PRISM	0051
MYRON & DAVIS	2101	PROSCAN	0261 0811 1421
NAD	0001 0401 1221		1691 2061 2301
	1311	PROTON	0001 0391 0641
NEC	0001 0251 0341		1221 1911 2231
	1221 1431 1801	PROVIEW	2401 2421
	1841 2151	PULSAR	0001 1781
NET TV	0121 0501	QUASAR	0051 0201 1091
NEXXTECH	0871 1201		1491 1571 1831
NIKEI	1941		1881 1961 2151
NIKKO	0001 1011 1221	RADIO SHACK	0001 0341 0931
NORCENT	0511 0671 2181		1001 1221 1261
NTC	1011		1421 1571 1691
OLEVIA	2431		1701 1911 1941
ONCOMMAND	1861		2111 2191
ONKING	1941	RCA	0001 0051 0091
ONWA	1941 2191		0251 0261 0361
OPTIMUS	0201 0401 1571		0551 0811 0891
	1881		1001 1131 1221
OPTOMA	2441		1331 1371 1421
OPTONICA	0341 1441		1521 1691 1851
ORION	0281 0371 1781		1921 2011 2061
PANASONIC	0051 0201 0951		2111 2151 2251
	1091 1491 1571		2301
	1651 1831 1881	REALISTIC	0001 0341 0931
	1961 2151		1001 1221 1261
PHILCO	0001 0251 0321		1421 1571 1691
	0961 1021 1221		1701 1911 1941
	1801 1961 2151		2191
	2321	RHAPSODY	0011
PHILIPS	0001 0161 0181	RUNCO	1771 1781 1841
	0321 0421 0541	SAMPO	0001 0121 0391
	0661 0701 0791		0501 1221 1911
	0911 0961 1021	SAMSUNG	0001 0101 0251
	1151 1171 1381		0261 0331 0351
	1391 1601 1801		0531 0571 0711
	1961 2151 2321		0781 1191 1221
PHILIPS-MAGNAVOX	0181 0681 0911		1311 1501 1911
	1171 1961 2321		2071 2141
PILOT	0001	SAMSUX	1221
PIONEER	0001 0401 1221	SAMTRON	0351
	1371 1511 1841	SANSUI	0371 1631
	1981	SANTECA	0171
PIVA	2411	SANYO	0001 0801 1051
POLAROID	2081 2271 2311		1161 1261 1531
PORTLAND	0001 0251 1011		1581 1911
	1081 1221 1551	SCOTCH	0001 1221

TV 04

SCOTT	0001 0021 0281 1221 1711 1941 2191	TEKNIKA	0001 0151 0251 0351 0961 1011 1221 1311 1421
SEARS	0001 0211 0261 0351 0701 0811 1221 1261 1291 1311 1381 1421 1531 1581 1691 1711 1911 1961 2021	TELECAPTION	0821
SELECTRON	2471 2491 2501	TELERENT	1421 1661 1691
SHARP	0001 0341 0461 0681 0691 1221 1291 1441 2031 2201 2261	TERA	0001 0641
SHOGUN	0001	TEVION	1141
SIGNATURE	1421 1661 1691 2171	TMK	0001 1221
SIMPSON	0961	TOSHIBA	0211 0231 0341 0351 0821 1121 1191 1261 1311 1351 1541 1571 1621 1801 1841 1911
SONIC	0011	TRUTECH	2461
SONY	1071 1641 1731 1901 2161	UNIVERSAL	0791 1951
SOUNDESIGN	0001 0961 1221 1711 1941 2191	VICTOR	1481
SPECTRAVISION	2341	VIDTECH	0001 0251 1221
SQUAREVIEW	1381	VIEWSONIC	0501 1981
SSS	0001 1941 2191	VIKING	0151
STAR SIGHT	0061	VIZIO	1741
STARLITE	2191	WARDS	0001 0021 0251 0321 0341 0791 0961 1021 1221 1321 1421 1661 1691 1711 1951 1961
SUPERSCAN	0701 1291 2021	WESTINGHOUSE	0111 2281
SUPERSONIC	0241	WHITE WESTINGHOUSE	0601 0931 1081 1501 1521 1551
SUPRA	0001 1991	YAMAHA	0001 0251 1221 1571
SUPREMACY	0151	ZENITH	0001 0061 0131 0371 0681 0691 0931 0941 0991 1011 1031 1081 1171 1181 1191 1221 1251 1271 1471 1631 1661 1751 1771 1781 1791 2171 2291
SUPREME	1901		
SVA	0671		
SYLVANIA	0001 0321 0371 0701 0931 0961 1021 1221 1381 1801 1821 1961 2321		
SYMPHONIC	0021 0701 0931 1381 2191		
SYNTAX	2431		
TANDY	1441		
TATUNG	1141 1741 2151		
TECHNICS	0051		
TECHWOOD	0001 0051 1221		

HDTV Set Top Boxes 01 HTIB (Home Theater in a Box) 01

GO VIDEO HDT100	2631	AIWA	0035 0586
HITACHI 61HDX98B	2661	AMW	0825
HUGHES HIRD-E8	2591 2651 2661	APEX	0425
HUGHES HTL-HD	2591 2651 2661	BOSE	1475
LG HTL-HD	2591 2651 2661	CENTRIOS	0955 1785 1845
LG LSS-3200A	2591 2651 2661	CLASSIC	1965
MINISUBISHI SRHD400	2661	CRITERION	0785
MINISUBISHI SR-HD5	2661	DURABRAND	0205 0955
MINISUBISHI SRHD500	2661	EMERSON	1185
MOTOROLA HRT100	2601	JVC	0155
PHILLIPS DSHD800R	2661	KLH	0465
PIONEER SH-D505	2561	KOSS	0215
PROSCAN PSHD105	2581	LENOXX	1345
RCA DTC-100	2581	LG	1565
RCA DTC-210	2581	MAGNAVOX	0295 0745 1045 0206
RCA HD65W20	2611	MYRON & DAVIS	1555
RCA PSHD105	2581	NESA	1555
SAMSUNG SIR-T165	2671	NEXXTECH	0955 1785
SAMSUNG SIR-T351	2671	NORCENT	0835
SAMSUNG SIR-TS160	2621	ONKYO	0355
SAMSUNG SIR-TS360	2621	PANASONIC	0165
SONY SATHD 100	2681	PHILIPS	0265 1045 0206
SONY SATHD 200	2681	PIONEER	0525
SONY SATHD 300	2681	RADIO SHACK	0085 0275 0955 1645 0626
SYLVANIA 6900DTD	2641	RCA	0955 1165 1645 0626
TOSHIBA DST3000	2591 2651	REGENT	1345
TOSHIBA DST3100	2591 2651	RIO	0205 0286
TOSHIBA DW65X91	2591 2651	SABA	0995
ZENITH DTV1080	2571	SAMSUNG	0075 1535
ZENITH HDSAT420	2571	SELECTRON	1885 2075
ZENITH HDSAT520	2571	SONY	0365
		TECHWOOD	1985
		TEVION	0785
		ZENITH	0205 0286

VCR 01

ACCELE	0102	EMERSON	0032 0102 0182
ADMIRAL	0302		0192 0232 0322
ADVENTURA	0992		0332 0412 0432
AIKO	1092		0442 0462 0602
AIWA	0182 0432 0752		0702 0732 0742
	0992		0752 0772 0882
AKAI	0032 0432 0502		0892 0912 0922
	0582 0712 0872		0942 0952 0982
	0982 1212		0992 1012 1032
ALLEGRO	0452 0792 1182		1092 1102 1112
AMERICAN HIGH	1112		1172 1192
APEX	0852	FISHER	0012 0042 0052
ASHA	0102		0472 0482 0592
AT&T	1272		0602 1202
AUDIO DYNAMICS	0012 0392 0532	FUJI	0712 1112
AUDIOVOX	0182	FUNAI	0412 0432 0702
BEAUMARK	0102		0992
BELL & HOWELL	0602	GARRARD	0992
BROKSONIC	0132 0322 0442	GE	0102 0162 0242
	0462 0572 0772		0612 1022 1112
	0892 0942		1152
CALIX	0182	GOLDSTAR	0012 0182 0432
CANDLE	0012 0022 0102		0792 1312
	0182 0882 1082	GO-VIDEO	0102 0272 0292
CANNON	0162 0802 1112		0402 0542 0662
CAPEHART	0792	GRADIENTE	0992
CARVER	0482	HARLEY DAVIDSON	0992
CCE	0372 1092	HARMAN KARDON	0012 0032
CINEVISION	0182	HARWOOD	0372
CITIZEN	0012 0022 0102	HEADQUARTER	0432 0512 0602
	0182 0882 1082		1142 1212
	1092	HI-Q	0592
COLORTYME	0012	HITACHI	0812
COLT	0372	INFINITY	0622
CRAIG	0102 0182 0372	INSIGNIA	0182
	0592	INSTANT REPLAY	0432 1112
CURTIS MATHES	0012 0082 0102	INTEQ	0182
	0162 0432 0482	JC PENNEY	0012 0102 0162
	0652 0732 1112		0182 0392 0532
CYBERNEX	0102		0602 0812 1112
DAEWOO	0022 0082 0762		1142 1212 1242
	0882 0892 0992	JCL	1112
	1082 1092	JENSEN	0812 1212
DBX	0012 0392 0532	JVC	0012 0392 0452
DIAMOND VISION	0422		0532 0602 0692
DIMENSIA	0162		1212
DURABRAND	0182	KENWOOD	0012 0392 0532
DYNATECH	0432 0992		0602 1212
ELECTROHOME	0032 0182	KLH	0372
ELECTROPHONIC	0182	KODAK	0182 1112
		LG	0432 0562 0792
		LLOYD	0432 0992

VCR 02

LOGIK	0372	PHILIPS	0092 0252 0342
LXI	0182 0432		0412 0482 0622
MAGNAVOX	0142 0162 0172		0672 1052 1112
	0302 0342 0412		1282
	0432 0482 0622	PHILIPS-MAGNAVOX	0302 0482 0622
	0792 0862 1112	PILOT	0182
MAGNIN	0102	PIONEER	0222 0392 0532
MARANTZ	0012 0392 0482		0812 1242
	0532 0602 0772	POLAROID	0852
	0802 1112	PORTLAND	0022 1082
MARTA	0182	PROSCAN	0162 0642
MATSUSHITA	1112	PROTEC	0372
MEDION	0422	PULSAR	0792
MEI	1112	QUARTER	0602
MEMOREX	0052 0102 0182	QUARTZ	0602
	0302 0432 0482	QUASAR	0122 0162 1062
	0502 0592 0602		1112 1262
	0792 0942 0992	RADIO SHACK	0032 0042 0102
	1112		0162 0182 0302
MGA	0032 0922		0432 0502 0592
MGN TECHNOLOGY	0102		0602 0722 0932
MIDLAND	0612		0992 1042 1112
MINOLTA	0812 1142		1152 1262
MIONTGOMERY WARD	0302 0932	RADIX	0182
mitsubishi	0032 0202 0392	RANDEX	0182
	0532 0632 0812	RCA	0062 0102 0162
	0922		0182 0212 0242
MOTOROLA	0302 1112		0352 0582 0612
MTC	0102 0432 0992		0642 0782 0812
MULTITECH	0102 0372 0432		1022 1112 1132
	0612 0992		1142 1152 1222
NEC	0012 0392 0532	REALISTIC	0032 0042 0102
	0602 0732 0772		0162 0182 0302
	1012 1122 1212		0432 0502 0592
NEXXTECH	0492 0842 0852		0602 0932 0992
NIKKO	0182		1042 1112 1262
NOBLEX	0102	REPLAYTV	1272
OLYMPUS	1112	RICOH	1252
OPTIMUS	0102 0122 0182	RIO	0182 0282
	0302 0722 1042	RUNCO	0792
	1062 1262	SAMSUNG	0102 0292 0502
OPTONICA	0102 0932		0652 0812 0872
ORION	0322 0942		0882
PANASONIC	0122 0162 0552	SANKY	0302 0792
	1062 1112 1262	SANSUI	0132 0322 0392
	1272		0532 0572 0942
PENTAX	0012 0812 1142		1212
PHILCO	0162 0172 0482	SANYO	0052 0102 0472
	1112		0592 0602
		SCOTT	0442 0462 0882
			0892 0922 1032
			1192

VCR 03

SEARS	0042 0132 0182 0412 0482 0592 0602 0812 1112 1142 1202 1242 1262	WHITE WESTINGHOUSE 0432 0762 XR-1000 0372 0992 1112 YAMAHA 0012 0392 0532 1212 ZENITH 0182 0302 0332 0392 0432 0452 0512 0532 0622 0652 0662 0712 0762 0792 0942 1072 1092 1182 1252
SHARP	0032 0302 0332 0432 0932 0962 1042 1082	
SHINTOM	0372 0522 0712 0812 1252	
SHOGUN	0102	
SIGNATURE	0432	
SINGER	0372 1112	
SONIC BLUE	1272	
SONY	0072 0112 0262 0382 0712 0822 0832 0972 1162 1232 1252	
STS	0812 1112 1142	
SUPERSCAN	0412	
SYLVANIA	0162 0312 0412 0432 0482 0702 0922 0992 1112	
SYMPHONIC	0312 0412 0432 0992	
TANDY	0432 0602	
TASHIKO	0182	
TATUNG	1212	
TEAC	0432 0992 1212	
TECHNICS	1112	
TEKNIKA	0182 0232 0432 0992 1112	
TiVo	1052 1162	
TMK	0102 0732 1012	
TOSHIBA	0042 0152 0482 0652 0682 0812 0882 0902 0922 1002 1032	
TOTEVISION	0102 0182	
UNITECH	0102	
VECTOR RESEARCH	0012 0392 0532 0882	
VICTOR	0392 0532	
VIDEO CONCEPTS	0012 0032 0392 0532 0882	
VIDEOSONIC	0102	
WARDS	0032 0102 0162 0182 0302 0362 0372 0432 0592 0812 0882 0932 0992 1032 1112 1142	

SAT/DTV/WebTV 01

AMPLICA	0103	PHILIPS	0203 0303 0443 0523 0533 0623 0703 0783
BELL EXPRESSVU	0073 0173 0343 0433	PHILIPS-MAGNAVOX	0203 0533 0783
CHANNEL MASTER	0283 0393 0483	PRIMESTAR	0323 0633
CHAPPARAL	0573 0653	PROSAT	0813
CHEYENNE	0653	PROSCAN	0333 0643 0723 0803 0873
DIRECTV	0203 0213 0233 0303 0353 0443 0523 0553 0623 0703 0793 0803 0853 0873	RCA	0333 0363 0543 0643 0723 0793 0803 0873
DISH NETWORK	0073 0403 0433 0493 0603 0783 0173 0343	REALISTIC	0273 0843
DISHPRO	0073 0403 0493 0603	SAMSUNG	0043 0233 0853
DRAKE	0023 0293 0733	SIERRA I II III	0653
DX ANTENNA	0383 0753	SKY NETWORK	0053 0133
ECHOSPHERE	0433	SONY	0113 0353 0553 0773
ECHOSTAR	0073 0173 0343 0403 0433 0493 0603 0783	STAR SIGHT	0863
EXPRESSVU	0073 0173 0343 0433	STAR TRAK	0423
FORTEC STAR	0083 0183 0263 0373 0463 0473	STARCHOICE	0163 0323 0633
FUJITSU	0673 0763	STS	0383 0583 0663
GE	0333 0543 0643 0723 0793 0803 0873	SUPER GUIDE	0513
GEMINI	0123	TOSHIBA	0063 0143 0303 0443 0523 0623 0713 0743
GENERAL INSTRUMENT (GI)	0013 0093 0163 0193 0323 0453 0633 0833 0893 0953 0963	ULTIMATE TV	0553 0873
GLOBECAST	0003	UNIDEN	0693 0823 0863
HITACHI	0303 0443 0523 0623	VIDEO CIPHER II	0023
HUGHES NETWORK	0303 0443 0523 0563 0593 0703	WEB TV	0113 0783
JVC	0433 0783	ZENITH	0023 0123 0153 0253 0293 0313 0733
KENWOOD	0413		
LUXOR	0503		
MACOM	0613		
MAGNAVOX	0203 0533 0783		
MITSUBISHI	0303 0443 0523 0623		
MOTOROLA	0453		
NORSTAT	0683		
PACE	0053 0133		
PANASONIC	0213 0223 0243		
PANSAT	0033 0883		

CABLE 01

ABC	0004 0074 0134 0464 0594	PIONEER	0024 0174 0274 0614
ADELPHIA	0514 0574	PULSAR	0154
ALLEGRO	0054 0114	RADIO SHACK	0064 0104 0114
AMERICAST	0254	RCA	0244 0394 0474
ANTRONIX	0264 0334	REALISTIC	0334
ARCHER	0264 0334 0404 0474	REGAL	0544
AT&T	0514	REGENCY	0214
BELL SOUTH	0254	REMBRANDT	0594
CABLETENNA	0264	ROGERS	0174
CABLEVIEW	0264	RUNCO	0154
CABLEVISION	0174	SAMSUNG	0014 0024
CENTURY	0474	SCIENTIFIC ATLANTA	0124 0134 0164 0174 0234 0294
CITIZEN	0474	SHAW	0574
COGECO	0514	SIGNAL	0514
COLOR VOICE	0534 0604	SIGNATURE	0014
COMCAST	0514	SL MARX	0594
COMTRONICS	0014 0084	SPRUCER	0014
CONTEC	0144	STANDARD	0394
DIGITAL MUSIC EXPRESS	0044	STAR SIGHT	0364
EASTERN	0214	STAR TRAK	0244
EVERQUEST	0014	STARCOM	0184
GARRARD	0474	STARGATE	0314 0464
GC ELECTRONICS	0334	TANDY	0014
GE	0384	TELEVIEW	0434
GEMINI	0204 0344	TEXSCAN	0014
GENERAL INSTRUMENT (GI)	0004 0044 0074 0314 0374 0464 0514 0594 0634	TIME WARNER	0364
HAMLIN	0414 0464 0484 0544	TOCOM	0174 0004 0444 0504
HITACHI	0594	TOSHIBA	0634
ILLICO	0174	TV86	0154
JASCO	0474	UNIKA	0224
JERROLD	0004 0074 0194 0314 0324 0444 0464 0594	UNITED CABLE	0264 0334 0474
MAGNAVOX	0094	UNIVERSAL	0464 0054 0264 0334
MEMOREX	0154	VIDEO TECH	0404 0474 0564
MOTOROLA	0004 0074 0194 0314 0374 0514 0594 0634	VIDEOTRON	0454
MOVIE TIME	0224	VIDEOWAY	0174
NSC	0224	VIEWSTAR	0034 0084 0094 0224
OAK	0144 0354	ZENITH	0434 0114 0154 0474 0524 0584 0624 0644
PANSONIC	0304 0394	ZENITH NETWORK	0254
PARAGON	0154 0284		
PHILIPS	0094 0344 0424 0474 0494 0554		
PHILIPS-MAGNAVOX	0064 0104		

DVD 01

ADVENT	1515	DVD 2000	1415
AFREEY	0575	ELTA	0055 0235
AIWA	0035	EMERSON	0205 0445 0795 0975 1185
AKAI	0195 0235	ESA	0515
AMES	1275	FARENHEIT	1205
AMW	0645 0825	FISHER	0405
ANABA	1375	FUNAI	0445 0795
APEX	0045 0245 0375 0425 0615 0845 0945 0965 1025 1065 1105 1235 1245 1405 1675	GE	0915 1105
ASPIRE	1695	GOLDSTAR	0205
A-TREND	1585	GO-VIDEO	0075 0255 0415 0565 0665 1275 1315 1385 1495
AUDIOVOX	1335	GPX	0135 0495
AXION	1335	GRADIENTE	0215
B & K	0885	GREENHILL	1105
BLAUPUNKT	1105	HAAZ	1295 1465
BODYSONIC	0575	HAIER	0315
BOSE	1475	HARMAN KARDON	0585
BOSS	1325	HITACHI	0025 0565 0765 0925
BROKSONIC	0015 0695 1525	HITEKER	0245
CENTRIOS	0955 1335 1365 1755 1765 1785 1795 1845 1875 1895 1935 1975 2015	HUMAX	1505
CHANGHONG	1245	ILO	1035 1945
CINEVISION	0205	INFINITY	0575
CITECH	2065	INITIAL	1105 1945
CITIZEN	2065	INSIGNIA	0205 0285 0445 1105 1335
CLASSIC	1245 1275 1965	INTEGRA	1435
COBY	0085 0245 0475 0485 0505 0675 0835	JBL	0585
CONCEPT	1105	JVC	0155 0395 0755 1145 1685 2025
CRITERION	0785	JWIN	0275 1065 1655
CURTIS INTERNATIONAL	0835 1005	KAWASAKI	0325 0955
CYBERHOME	0175 1015 1585	KENWOOD	0935 1075
CYTRON	0435 0725	KISS	0765
DAEWOO	0065 0345 1115 1285 1385	KLH	0375 0465 1105
DENON	1075 1265	KONKA	0285 1085 1255 1425 1605
DENZEL	0765	KOSS	0215 0725
DESAY	0865	KXD	0085
DIAMOND VISION	0455 0855 1485	LASONIC	0855 1295
DIGITREX	0245	LENOXX	0235 1345
DIGIX	0125	LG	0205 0635 1565
DISNEY	0795	LINN	1635
DUAL	0005 0435 0515 0605 0765	LIQUIDVIDEO	1335
DURABRAND	0205 0435 0955	LITEON	0805 1035 1495 1575 1905
		MAGNAVOX	0105 0295 0445 0735 0745 1045 1055 1225 1395

DVD		02	
MARANTZ	0205 0735 0745	RIO	0205
	1395 1615	RJ TECHNOLOGY	1825
MAXENT	1685	ROSEN	1175
MEDION	0435 0455 1035	ROTEL	0395
	1325 1665	SABA	0995
MEMOREX	0435 1925	SAMPO	0575
MERIDIAN	0735	SAMSUNG	0075 0255 0565
MICROSOFT	0915		1305 1535 1725
MINTEK	1105	SANSUI	0015 0695
MITSUBISHI	1415	SANYO	0095 0405
MUSTEK	1275	SEARS	0015 0445
MYRON & DAVIS	1555	SEG	0765
NAD	0205 1625	SELECTRON	1855 1885 1915
NAKAMICHI	1445		1955 1995 2035
NESA	1105 1555		2075
NEXXTECH	0125 0145 0335	SHARP	0555 0625 0815
	0515 0955 1025	SHERWOOD	0225
	1545 1755 1765	SHINCO	1105
	1785 1815 1835	SHINSONIC	1105
	2005 2055	SONIC BLUE	0665
NORCENT	0305 0485 0655	SONY	0365 0535 0715
	0835 1575		0725 0895 0905
ONKYO	0355 1435	SOUNDSTORM	1155 1325
OPTIMUS	0025	SUNGALE	1715
ORION	0015	SUPERSCAN	0445
ORITRON	0215 1935	SUPERSONIC	0135
PACIFIC	0435	SV2000	0445
PANASONIC	0165 0385 0545	SYLVANIA	0445 0795
	0595 1075 1195	SYMPHONIC	0445 0795 0975
	1215	TEAC	0025 0955
PHILIPS	0265 0445 0735	TECHNICS	1075
	0745 0795 1045	TECHWOOD	1625 1985
	1055 1225 1395	TERAPIN	1705
	1615	TEVION	0435 0605 0725
PHILIPS-MAGNAVOX	0735 0745 1055		0785 1125 1295
	1225 1615		1465
PIONEER	0025 0525 0985	THETA DIGITAL	0025
	1595	TIVO	0985 1505
PIVA	1805	TOSHIBA	0015 0115 0735
POLAROID	0185 0685 1025		1735 1745
POLK AUDIO	0735 0745 1395	TREDEX	1355
PORTLAND	0235	TRUTECH	2045
PROLINE	0215	UNITED	0955
PROSCAN	0915 1135	VENTURER	0955
PROSONIC	0485	WHARFEDALE	0575 1455
PYLE	1155	WHITE WESTINGHOUSE	0795
RADIO SHACK	0955 0995 1165	X-BOX	0915
	1645	XENIUS	0725
RCA	0915 0955 1105	YAMAHA	0745 1055 1075
	1135 1165 1645		1095 1225
REGENT	1345	YAMAKAWA	0765 0775 1865
REOC	1295	ZENITH	0205 0635

AUDIO		01	
AIWA	0586 0846 0966	TECHNICS	0056 0126 0696
APPLE IPOD	0186		0796 1066 1096
BOSE	0886	VENTURER	0086
CENTRIOS	1116	XM RADIO	0376
DELPHI	0376	YAMAHA	0076 0336 0446
DENON	0316 0976 1046		0456 0596 0706
FISHER	0026 0826		0806 0836 0926
GOLDSTAR	0216	ZENITH	0026 0096 0216
HARMAN KARDON	0016 0436		0286 0506 0516
IPOD	0066		0656 0716
JVC	0566 0676 1056		
KENWOOD	0246 0426 0616		
	0956 1016		
MAGNAVOX	0026 0206 0226		
MARANTZ	0036		
MITSUBISHI	0366		
NAD	0496 0766 1026		
NEO	0076		
NEXXTECH	0536 0576 0666		
	0856 0916 1116		
ONKYO	0116 0816 0936		
	0996		
OPTIMUS	0006 0386 0506		
	0776 0896 1036		
PANASONIC	0056 0126 0686		
	0746 0796 0876		
	1066 1096		
PHILIPS	0026 0036 1066		
PIONEER	0266 0356 0476		
	1106		
RADIO SHACK	0006 0166 0176		
	0236 0266 0356		
	0476 0626 1036		
RCA	0146 0176 0196		
	0266 0276 0326		
	0356 0476 0486		
	0626 0736 0786		
	0866 0906 0986		
REALISTIC	0946		
SCOTT	0396		
SHARP	0556 0756		
SHERWOOD	0236 0466 0606		
SKYFI	0076		
SONY	0046 0106 0136		
	0256 0296 0406		
	0416 0526 0546		
	0636 1006 1076		
	1086		
TAO	0076		
TEAC	0156 0306 0346		
	0646		

CD		01	
ADC	0517	PANASONIC	0257 0707 0747
ADCOM	0027 0777		0997 1077
AIWA	0357 0987 1007	PHILIPS	0197 0207 0837
AKAI	0167 0377 0757	PIONEER	0307 0407 0427
AUDIO TECHNICA	0117		0577 0717 0807
CALIFORNIA AUDIO LABS	0257		0917
CAPETRONIC	0527	PROTON	0207
CARVER	0197 0207 0317	QUASAR	0257
	0417	RADIO SHACK	0107 0247 0267
CASIO	0397		0307 0417 0507
CENTRIOS	1097		0557 0717
CITIZEN	0277	RCA	0087 0107 0187
CURTIS MATHES	0397		0307 0317 0717
DENON	0637		0777 1047 1067
EMERSON	0777 1017		1117
FISHER	0127 0217 0317	REALISTIC	0317 0347 0427
	0327 0457		0527 0547 0557
GENEXXA	0427 0577 1017		0777 1017
GOLDSTAR	0687	ROTEL	0207
HARMAN KARDON	0647 0797	SAE	0207
HITACHI	0427	SAMSUNG	0847
INKEL	0787	SANSUI	0017 0047 0207
JC PENNEY	0397 0657		1067
JVC	0897 1107	SANYO	0157 0177 0317
KENWOOD	0137 0367 0467		0457 0957
	0497 0537 1027	SCOTT	0777 1017
KRELL	0207	SEARS	0397 0537 0547
KYOCERA	0517	SHARP	0537 0547
LUXMAN	0227 0337 0477	SHERWOOD	0247 0447 0547
	0587		0627 0787
LXI	0397	SHURE	0657
MAGNAVOX	0207 0737 0837	SONY	0077 0357 0737
MARANTZ	0207 0437 0547		0977
	0947	STS	0517
MCS	0397 0657	SYLVANIA	0207
MGA	0797	SYMPHONIC	0567
MISSION	0207	TEAC	0217 0297 0547
MITSUBISHI	0797 0907		0557 0567 0677
NAD	0827 1087		0817
NAKAMICHI	0007 0877 1037	TECHNICS	0257 0747 0997
NEC	0657		1077
NEXXTECH	0097 0487 0607	THETA DIGITAL	0837
	0617 0727 0887	TOSHIBA	0827
	0967	VICTOR	0897
NIKKO	0117 0217 1017	YAMAHA	0037 0117 0287
NSM	0207		0927 1057
ONKYO	0147 0237 0867	ZENITH	0067 0217 0597
	0937		0697 0767
OPTIMUS	0057 0317 0347		
	0387 0417 0427		
	0447 0537 0557		
	0667 0857		

14

DVR		01 DVD-Recorders + RW		01
AT&T	1272	APEX	0845	
HUGHES	0593	ASPIRE	1695	
HUMAX	1505	BROKSONIC	0695	
PANASONIC	0545 1272	CENTRIOS	1365 1935 1975	
PHILIPS	0092 0252 1052	COBY	0085	
PIONEER	0532 0985	CYBERHOME	1015	
RCA	0915	EMERSON	0975	
REPLAYTV	1272	GO-VIDEO	1275 1315 1495	
SONIC BLUE	1272	HITACHI	0925	
SONY	0353 1162 1302	HUMAX	1505	
TiVo	0092 0252 0353	ILO	1035	
	0985 1052 1162	JVC	1145 2025	
	1505 1745	KXD	0085	
TOSHIBA	1745	LG	0635	
		LITEON	0805 1035 1495	
		MAGNAVOX	1055 1225	
		MEDION	1035 1665	
		MEMOREX	1925	
		MUSTEK	1275	
		ORITRON	1935	
		PANASONIC	0545	
		PHILIPS	1055 1225	
		PHILIPS-MAGNAVOX	1055 1225	
		PIONEER	0985	
		POLAROID	0185	
		RCA	0915	
		SAMSUNG	1305	
		SANYO	0095	
		SELECTRON	1955	
		SHARP	0625	
		SONY	0535 0715 0895	
		SYMPHONIC	0975	
		TOSHIBA	0735 1735	
		TRUTECH	2045	
		YAMAHA	1055 1225	
		ZENITH	0635	

Laser Disc		01
------------	--	----

DENON	0222
PIONEER	0222
PROSCAN	0642
RCA	0642
SANYO	1072
SONY	1232
ZENITH	1072

15

TV/VCR Combos 01 TV/DVD Combos 01

ADMIRAL	0302	APEX	0191 1245
AIWA	0432 0752	ADVENT	1515
AKAI	0032	AXION	0881 1335
BROKSONIC	0851 0462 0892	BROKSONIC	0015
	0942	CHANGHONG	0191 1245
CURTIS MATHES	0652	CLASSIC	0191 1245
DAEWOO	1081 1251 0762	DAEWOO	1561 0065
	1092	DIAMOND VISION	1611 2001 0455
DIAMOND VISION	2001 0422		0855
DURABRAND	2291 0182	DURABRAND	2291 0205
ELECTROHOME	0032	EMERSON	0445
EMERSON	0851 1251 0032	FUNAI	0445
	0192 0232 0332	GPX	0135
	0432 0462 0892	HAIER	0315
	0942 1092 1172	ILO	1945
FISHER	0602	INITIAL	1945
FUNAI	0432	INSIGNIA	1241 0285 0445
GE	1152	JVC	1685
GOLDSTAR	1181 0432	KAWASAKI	0325
HITACHI	0432	KONKA	1425 1605
INFINITY	0622	LASONIC	1611 0855
JVC	0452	LIQUIDVIDEO	0881 1335
LG	1181 0432	MAGNAVOX	0445
LXI	0432	MEMOREX	0015
MAGNAVOX	0302 0412 0622	NEXXTECH	2005
MEMOREX	0602 0942	PANASONIC	0595 1195
MITSUBISHI	0032	PHILIPS	1381 0445 0795
OPTIMUS	0122 1062	PIVA	1805
PANASONIC	0122 1062	SAMSUNG	1535
PHILIPS	0412 0622	SANSUI	0015
PHILIPS-MAGNAVOX	0302 0622	SEARS	0015
QUASAR	0122 1062	SUPERSONIC	0135
RADIO SHACK	0432 1152	SYLVANIA	0445
RCA	1152	SYMPHONIC	0445
REALISTIC	0432	TOSHIBA	0015 0115
SAMSUNG	2141 0652		
SANSUI	0942		
SANYO	0602		
SHARP	0302 0332		
SONY	0972 1292		
SYLVANIA	0432		
SYMPHONIC	0432		
TOSHIBA	0652 0902		
WHITE WESTINGHOUSE	1081 0432 0762		
ZENITH	1081 1181 1251		
	2291 0182 0302		
	0332 0432 0452		
	0622 0652 0762		
	0942 1092		

TV/VCR/DVD Combos 01

BROKSONIC	1525
DIAMOND VISION	2001 0455
MAGNAVOX	0445
PANASONIC	0595
PHILIPS	0445
SAMSUNG	1535
SEARS	0445
SUPERSCAN	0445
SYLVANIA	0445
TOSHIBA	0115

DVD/VCR Combos 01 DVD/SAT Combos 01

APEX	1025	BELL EXPRESSVU	0173 0343
BROKSONIC	0015 0695	DISH NETWORK	0173 0343
CINEVISION	0182 0205	ECHOSTAR	0173 0343
DAEWOO	1385	EXPRESSVU	0173 0343
DIAMOND VISION	0455	FORTEC STAR	0083 0183 0473
DURABRAND	0182 0205	HUGHES NETWORK	0593 0703
EMERSON	0432 0445 0795	PHILIPS	0703
FISHER	0472 0405	PROSCAN	0873
FUNAI	0432 0445 0795	RCA	0873
GO-VIDEO	0255 0415 0565	SAMSUNG	2671
	1385	SONY	0353 0553
HITACHI	0925 0432	ULTIMATE TV	0553 0873
INSIGHIA	0182 0205	ZENITH	0253
JVC	0755 1145		
LG	0635		
LITEON	1905		
MAGNAVOX	0342 0105 0445		
	1045		
MEDION	0455		
NEXXTECH	0492 0955 1025		
	2055		
PANASONIC	0595		
PHILIPS	0342 0445 1045		
POLAROID	1025		
RCA	0162 0915		
RIO	0182 0205		
SAMSUNG	0255 1725		
SANSUI	0015 0695		
SANYO	0472 0405		
SEARS	0015		
SONY	0832		
SYLVANIA	0312 0432 0445		
	0795		
SYMPHONIC	0312 0432 0445		
	0795 0975		
TECHWOOD	1985		
TOSHIBA	0115 0735		
WHITE WESTINGHOUSE	0432 0795		
ZENITH	0182 0205		

DVR/CABLE Combos 01

CABLEVISION	0174
ILLICO	0174
PIONEER	0174
ROGERS	0174
SCIENTIFIC ATLANTA	0174
TIME WARNER	0174
VIDEOTRON	0174

DVR/DVD Combos 01 HOME AUTOMATION 01

HUMAX	1505	GE HOMEMINDER	0008
ILO	1035	HOME AUTOMATION	0018
JVC	2025	X10 (NEC)	0028
LITEON	1035		
MEDION	1035		
PANASONIC	0545		
PIONEER	0985		
TIVO	0985 1505		
TOSHIBA	1735 1745		